

## Check Valves

### Standard Check Valves

*(for use between hose and nozzle)*

For use with fuel delivery hose

- Cast bronze construction
- Brass stems
- Buna seals

Part #	Male NPT	Female NPT	Description
<b>1210</b>	1¼"	1¼"	STD spring <sup>1</sup>
<b>1220</b>	1½"	1½"	STD spring <sup>1</sup>
<b>1230</b>	1½"	1¼"	STD spring <sup>1</sup>
<b>1209</b>	1¼"	1¼"	HD spring <sup>2</sup>
<b>1219</b>	1½"	1½"	HD spring <sup>2</sup>




<sup>1</sup> STD spring opens at 2 PSI

<sup>2</sup> HD spring opens at 7 PSI

### Union Check Valve

*(stops suction line leaks)*

Part #	Female NPT	Female NPT
<b>1590</b>	1½"	1½"



## Angle Valves

- Rotation of cap controls gravity flow from above ground gasoline storage tank
- Inlet (*pipe from storage tank*) x outlet (*for hose and nozzle dispensing*)
- Lockable (*lock not included*)
- Cast non-ferrous alloy construction

Part #	Inlet Size	Outlet Size
<b>500AV</b>	1"	1"
<b>525AV</b>	1¼"	1¼"

