

# PICTORAL INDEX

## Air Brake - Copper

Pages 111-115

Sleeve	Nut	Union	Tee	Elbow
F Adapter	M Adapter	90° M Elbow	90° F Elbow	Run Tee
Branch Tee	45° M Elbow			

## Air Brake - Hoses/Ends

Pages 116-118

Sleeve	Nut	Nut	Nut / Spring	Adapter Body
M Adapter	M Adapter	Spring	Union	F Connector
M Connector	Adapter			

## D.O.T. Push-In

Pages 119 -125

Male 45°	Male Swivel	Plug	Union	Union Tee
Union Elbow	F Connector	M Connector	Male Elbow	M Swivel
M Run Tee	M Swivel Run	Male Branch	Bulk/Union	F Bulk/Union

# PICTORAL INDEX

## Air Brake - Accessories

Pages 126-129

Collet	Tubing	No Hub	Seal	Hex Foot Chuck
1/4 I.D. Barb	Dual Foot	Angle Chuck	Steel Brake	Hose
Fuel Line	Airbrake Tube	M Connector	90° M Elbow	Long Ells
Ext. Adapters				

## Drain Cocks

Pages 150-151

Shut Off	Drain Valve	Drain Cock	Truck Drain	Shut Off
Lever Handle	Internal Seat	Internal Seat	Long Seat	Bibb Needle
Needle Valve	Radiator Type			

## Shut-Off Cocks

Pages 152-153

Flare X Male	Flare X Flare	Flare X F	Comp X M	F X F
M X F	M X M			

## Brass Air Cocks

Pages 154-157

MIP X BIBB	MIP X BIBB	MIP X MIP	MIP X MIP	MIP X BIBB
MIP X BIBB	FIP X FIP	MIP X FIP		

