

Table of Contents

Hose
A

Size

Flow Capacities at Recommended Flow Velocities E-3
 Hose Flow Capacities Pressure Drop.....E-4

Fittings
B

Temperature

Temperature/Pressure Chart - 201, 206, 213, and 266 Hose.....E-5
 Minimum/ Maximum Temperature ChartE-6

Equipment
C

Application

Hose Installation TipsE-10
 Ferrule-FixE-11
 Hose, Adapters and Fittings Standards and Specifications.....E-12
 Assembly MethodsE-15
 Thread Guide.....E-16
 Standard Fitting Configurations by Connection and End CodeE-17
 Metric Conversions.....E-19

Accessories
D

Media

Chemical Resistance Information..... E-20

Technical
E

Pressure

Working Pressure ChartE-30
 Pressure Rating of Hose End ConnectionsE-32
 Metric Pressure ConversionsE-33

Part Number IndexE-34
 Fitting Size Identification Chart.....E-38

Safety Guide & MSDS Statement.....E-40
 Offer of SaleE-43